



TELEDYNE FLIR OFFERS ÇANAKKALE BRIDGE TRAVELERS A SAFER CROSSING

Teledyne FLIR recently installed its dual thermal AID camera technology for use on the new 1915 Çanakkale Bridge in Turkey. With incident detection cameras covering the entire length of the 4.6 km bridge, Teledyne FLIR technology will allow traffic users to cross the Çanakkale Strait in a fast and safe way.

1915 Çanakkale Bridge, part of the Malkara-Çanakkale Motorway, is expected to be a huge contribution to the region and country's economy. The new suspension bridge that runs from Çanakkale to Malkara will decrease the time it takes to cross the Çanakkale Strait to six minutes.

The construction of the bridge was by joint venture between DL E&C (formerly Daelim), Limak, SK Ecoplant and Yapı Merkezi. With its 4608-meter length, 1915 Çanakkale Bridge is the longest mid-span suspension bridge in the world to date. The deck carries six lanes of motorway (three in each direction), together with two walkways on each side for maintenance purposes.

WEATHER-PROOF INCIDENT DETECTION

From the onset, the consortium was looking for a high-performance automatic incident detection (AID) system that was able to deliver reliable detection results in all weather conditions. To be able to monitor the bridge traffic efficiently, the bridge operators needed some kind of visual component. At the same time, operators needed to be able to see clearly in various environmental conditions as well, including foggy weather and heavy rain. Another difficulty was the risk of sun glare which could distort the images generated by a visual camera based automatic incident detection system.

That is why very early on the consortium was already looking at thermal imaging camera technology. From the start, Teledyne FLIR pointed out the vast possibilities of a thermal AID system. Since thermal cameras can detect traffic based on heat patterns, not light, they have no issues whatsoever with fog, bad weather or sun glare.

"By organizing successful demos with FLIR thermal AID cameras and an informative visit to the Turkish Eurasia tunnel underneath the Bosphorus Strait, where similar FLIR AID technology is used, we were able to convince the consortium that Teledyne FLIR was the preferred partner to work with," says Hesham Enan, Key Account Manager, ITS at Teledyne FLIR.

"Winters can be hard in Çanakkale and Malkara, with snow, fog and heavy wind," says Emrah Ilteray, Chairman of the Board at Elmak-YMİdis,



the joint venture responsible for ITS part of the project. "That's why we needed thermal cameras to secure accurate incident detection. At the same time, we wanted to give operators a crisp visual image as well. Teledyne FLIR was the only company that could combine these capabilities into a reliable camera solution."

THERMAL- AND VISIBLE-LIGHT CAMERA IN ONE

Teledyne FLIR provided 98 units of the ITS-632 Dual AID camera to be installed along the entire bridge length every 96 meters on each side. This camera combines best-in-class thermal and visual imaging technology with advanced video analytics to provide a complete solution for automatic incident detection. The camera can reliably detect incidents—including collisions, stopped vehicles, wrong-way drivers and pedestrians—in challenging lighting and weather conditions. In addition, the camera also detects fires within seconds of ignition and provides valuable traffic data, including number of vehicles and vehicle classes. The visible-light camera offers bridge operators a way to verify incidents in real time in a visual way. The visual footage can also be used as forensic evidence after an incident.

In addition to the incident detection cameras, Teledyne FLIR also delivered 8 of its FLIR Elara DX-Series multispectral pan/tilt/zoom (PTZ) security cameras, which offer control room operators extra means to monitor the bridge for incidents.

"The 1915 Çanakkale Bridge is a high-profile project with international impact," says İlteray. "That's we did not want to compromise on the quality of our incident detection technology. FLIR's Dual AID camera ticks all the boxes in terms of detection performance and accuracy, and the support from the company to realize this project has been nothing but amazing."

AID ON THE EDGE

One of the strengths of Teledyne FLIR's dual series AID cameras, which knocked most of the company's competitors out of the park, is that they have their video analytics embedded within the camera. Since the camera takes care of all the video analytics processing, the video stream does not need to be sent over the network to a central processing server. This significantly reduces network traffic and results in much lower latency. And in case the network should go down, the camera can still store its incident events. Another benefit of such a distributed architecture is that in the rare case that an AID camera should go down, the rest of the network and camera infrastructure are not affected.

MANAGING SOURCES IN THE CONTROL ROOM

Information coming from the 98 AID cameras and 8 security cameras is collected and managed by FLIR's Flux video detection management system. Control room operators use this software to overview traffic data, events, alarms and video images generated by the various cameras. Flux provides a user-friendly interface composed of a monitoring and a reporting application and enables real-time monitoring of events and alarms.

For more information about FLIR traffic solutions or about this application please visit: <https://www.flir.com/traffic/incident-detection/>



FLIR ITS Dual AID Series



FLIR Elara DX-Series



www.teledyneflir.com

Teledyne FLIR, LLC
27700 SW Parkway Avenue
Wilsonville, OR 97070
USA
PH: +1 866.477.3687

Equipment described herein is subject to US export regulations and may require a license prior to export. Diversion contrary to US law is prohibited. ©2022 Teledyne FLIR, LLC. All rights reserved. Created 02/22